



ENGLISH

ATTENTION

- Do not use S-VHS cassette to record program in D-VHS mode. D-VHS recording made on S-VHS cassette may cause block noise. Use D-VHS cassette only when you record program in D-VHS mode.
- When block noise appears on the TV screen, clean the video heads by playing back DFC-2 D-VHS cleaning cassette for 15-seconds. If it persists, repeat the procedure until the block noise clears. Consult your JVC dealer if block noise does not clear.

FRANÇAIS

ATTENTION

- Ne pas utiliser une bande S-VHS pour enregistrer un programme en mode D-VHS. Il risque d'y avoir du bruit de bloc si un enregistrement D-VHS est effectué sur une bande S-VHS. N'utiliser une bande D-VHS que pour enregistrer un programme en mode D-VHS.
- Lorsque du bruit de bloc apparaît sur l'écran TV, nettoyer les têtes vidéo en faisant la lecture de la cassette de nettoyage D-VHS DFC-2 pendant 15 secondes. Si le bruit persiste, répéter la procédure jusqu'à ce qu'il disparaisse. Si le bruit de bloc ne disparaît pas, consulter un revendeur JVC.